

## Antiblocking Agent

An Antiblocking agent is recommended to prevent sticking of stored impregnated papers.

HIPE®ADD A is usually added in the MF bath and can be added in smaller amounts to the first impregnation bath (pure UF resin or UF/MF mixture) in order to prevent urea migration to the top of the impregnated paper.

NAME	DOSAGE	BENEFIT
HIPE®ADD A	0,3% - 0,5% in MF bath 0,1% - 0,3% in UF bath	<ul> <li>■ Prevents the sticking of impregnated papers during storage</li> <li>■ Prevents the migration of urea to the top of the impregnated paper</li> </ul>

